


Body-Solid



Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Казахстан (772)734-952-31

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Таджикистан (992)427-82-92-69


Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: bda@nt-rt.ru || www.bodysolid.nt-rt.ru


CCO-150.1 OWNER'S MANUAL

CCO-150 ASSEMBLY INSTRUCTIONS


HARDWARE ILLUSTRATION




(A1)HEX BOLT 1/2"X2 1/4"L PARTIAL THREAD QTY.4




(A2)HEX BOLT 1/2"X3 1/4"L PARTIAL THREAD QTY.8




(A3)HEX BOLT 1/2"X6 1/2"L PARTIAL THREAD QTY.2




(A4)HEX BOLT 3/8"X1 3/4"L PARTIAL THREAD QTY.8




(A5)HEX BOLT 3/8"X3"L PARTIAL THREAD QTY.2



(A6)ROUND HEAD SQUARE NECK BOLT 3/8"X2 3/4"L PARTIAL THREAD QTY.4




(A7)ROUND BOLT 3/8"X1 1/2"L PARTIAL THREAD QTY.2




CCO-150 ASSEMBLY INSTRUCTIONS

HARDWARE ILLUSTRATION





(A8)10LB PIN(8250-019) QTY.1





CCO-150 ASSEMBLY INSTRUCTIONS



HARDWARE ILLUSTRATION




(B1)NYLON LOCK NUT 1/2" QTY.14




(B2)LOCK NUT 1/2" QTY.2




(B3)NYLON LOCK NUT 3/8" QTY.14




(C1)1/2"(I.D.)FLAT WASHER Ø25 QTY.4




(C2)1/2"(I.D.)FLAT WASHER Ø34 QTY.24



(C3)1/2" SPRING WASHER QTY.2



(C4)3/8"(I.D.)FLAT WASHER Ø27 QTY.24



(C5)3/8" SPRING WASHER QTY.2




CCO-150 ASSEMBLY INSTRUCTIONS


HARDWARE ILLUSTRATION

D1. 2"X2" END CAP(9211-006)	[4PCS]
D2. 2"X2"(2.5t)FOOT CAP(9211-025)	[8PCS]
D3. 60x50 NYLON BUSHING(9211-033)	[4PCS]
D4. Ø3/4" SHAFT COLLAR(9211-046)	[4PCS]
D5. Ø2 1/2" RUBBER DOUNT(9310-010)	[4PCS]
D6. Ø2 1/2" RUBBER DOUNT(9310-011)	[4PCS]
D7. 130mm PULL UTENSIL(8290-006)	[2PCS]
D8. Ø8mm SPRING SNAP LINK(8810-001)	[2PCS]
D9. 7330mm STEEL CABLE	[2PCS]
D10. WEIGHT SELECTOR BAR(8210-052)	[2PCS]
D11. Ø110 PULLEY(9213-002C)	[8PCS]
D12. Ø114 PULLEY(9213-010B)	[4PCS]
D13. Ø109 PULLEY(9213-022A)	[2PCS]


D1



D2




D3



D4




D5



D6




D7




D8




D9




D10




D11



D12



D13




CCO-150 ASSEMBLY INSTRUCTIONS

HARDWARE ILLUSTRATION

D14. TOP PLATE(8400-009)-----[2PCS]


D14




CCO-150 ASSEMBLY INSTRUCTIONS

PARTS ILLUSTRATION SHEET


A[1PCS]




B1[1PCS]




C1[1PCS]




D[2PCS]




E[2PCS]




G1[2PCS]



F[1PCS]




H[1PCS]



PARTS ILLUSTRATION SHEET

I[1PCS]




J[4PCS]




CCO-150 ASSEMBLY INSTRUCTIONS

ASSEMBLY STEP 1




CCO-150 ASSEMBLY INSTRUCTIONS

ASSEMBLY STEP 2




CCO-150 ASSEMBLY INSTRUCTIONS

ASSEMBLY STEP 3




ASSEMBLY STEP 4



*:Before the assembling of the weight stacks:
Finish (step 3) and adjust the distance between
the two bases to 2640mm(104in)


CCO-150 ASSEMBLY INSTRUCTIONS

ASSEMBLY STEP 5




CCO-150 ASSEMBLY INSTRUCTIONS

ASSEMBLY STEP 6



CCO-150 ASSEMBLY INSTRUCTIONS

Wire Rope illustration



Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Казахстан (772)734-952-31

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Таджикистан (992)427-82-92-69

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: bda@nt-rt.ru || www.bodysolid.nt-rt.ru