





Архангельск (8182)63-90-72	Ижевск (3412)26-03-58	Магнитогорск (3519)55-03-13	Пермь (342)205-81-47	Сургут (3462)77-98-35
Астана (7172)727-132	Иркутск (395)279-98-46	Москва (495)268-04-70	Ростов-на-Дону (863)308-18-15	Тверь (4822)63-31-35
Астрахань (8512)99-46-04	Казань (843)206-01-48	Мурманск (8152)59-64-93	Рязань (4912)46-61-64	Томск (3822)98-41-53
Барнаул (3852)73-04-60	Калининград (4012)72-03-81	Набережные Челны (8552)20-53-41	Самара (846)206-03-16	Тула (4872)74-02-29
Белгород (4722)40-23-64	Калуга (4842)92-23-67	Нижний Новгород (831)429-08-12	Санкт-Петербург (812)309-46-40	Тюмень (3452)66-21-18
Брянск (4832)59-03-52	Кемерово (3842)65-04-62	Новокузнецк (3843)20-46-81	Саратов (845)249-38-78	Ульяновск (8422)24-23-59
Владивосток (423)249-28-31	Киров (8332)68-02-04	Новосибирск (383)227-86-73	Севастополь (8692)22-31-93	Уфа (347)229-48-12
Волгоград (844)278-03-48	Краснодар (861)203-40-90	Омск (3812)21-46-40	Симферополь (3652)67-13-56	Хабаровск (4212)92-98-04
Вологда (8172)26-41-59	Красноярск (391)204-63-61	Орел (4862)44-53-42	Смоленск (4812)29-41-54	Челябинск (351)202-03-61
Воронеж (473)204-51-73	Курск (4712)77-13-04	Оренбург (3532)37-68-04	Сочи (862)225-72-31	Череповец (8202)49-02-64
Екатеринбург (343)384-55-89	Липецк (4742)52-20-81	Пенза (8412)22-31-16	Ставрополь (8652)20-65-13	Ярославль (4852)69-52-93
Иваново (4932)77-34-06	Киргизия (996)312-96-26-47	Казахстан (772)734-952-31	Таджикистан (992)427-82-92-69	

Единый адрес для всех регионов: bda@nt-rt.ru || www.bodysolid.nt-rt.ru


GLP OWNER'S MANUAL

GLP ASSEMBLY INSTRUCTIONS


HARDWARE ILLUSTRATION




(A1)HEX BOLT 1/2"X3 1/4" PARTIAL THREAD QTY.2




(A2)HEX BOLT 3/8"X1 3/4" PARTIAL THREAD QTY.3




(A3)HEX BOLT 13/8"X2" PARTIAL THREAD QTY.2




(A4)HEX BOLT 3/8"X3" PARTIAL THREAD QTY.4



(A5)HEX BOLT 3/8"X3 1/4" PARTIAL THREAD QTY.2




(A7)HEX BOLT 3/8"X4 1/4" PARTIAL THREAD QTY.2




GLP ASSEMBLY INSTRUCTIONS


HARDWARE ILLUSTRATION




(A8)HEX BOLT 5/16"X1" PARTIAL THREAD QTY.4



(A9)HEX BOLT 5/16"X3 3/4" PARTIAL THREAD QTY.2





(A10)HEX BOLT 3/8"X2 1/2" PARTIAL THREAD QTY.2




GLP ASSEMBLY INSTRUCTIONS



HARDWARE ILLUSTRATION




(B1)NYLON LOCK NUT 1/2" QTY.2




(C4)5/16"(I.D.)FLAT WASHER Ø24 QTY.6




(B2)NYLON LOCK NUT 3/8" QTY.15




(C1)1/2"(I.D.)FLAT WASHER Ø34 QTY.4



(C2)3/8"(I.D.)FLAT WASHER Ø27 QTY.30



(C3) 5/16"SPRING WASHER QTY.6



GLP ASSEMBLY INSTRUCTIONS

HARDWARE ILLUSTRATION

- D1. Ø6 Spring Snap Link (8810-001)-----[1PCS]
D2. □50x2.5T Round End Cap (9211-088)-----[4PCS]
D3. 2"x2" Foot Cap (9211-025)-----[1PCS]
D4. 45X60 Nylon Bushing (9211-047)-----[1PCS]
D6. 45X50 Rubber Dount(9212-039)-----[1PCS]
D7. Ø1 Round End Cap (9260-021)-----[2PCS]
D8. 4205 Steel Cable-----[1PCS]
D9. Ø4 1/4" Pulley(9213-002C)-----[5PCS]


D1




D2




D3




D4



D6




D7



D8




D9




GLP ASSEMBLY INSTRUCTIONS

PARTS ILLUSTRATION SHEET


A1[1PCS]




B[1PCS]




C[1PCS]




D[1PCS]




E[1PCS]




F[1PCS]




G[1PCS]



H[2PCS]




J[2PCS]
8312-090




K[2PCS]
8510-005




L[1PCS]
9121-045



M[1PCS]
9111-049



N[1PCS]




GLP-072004


IF Mode A: □50X50 Steel Tube
uses A4 Bolt for G6B,G5S--(2PCS each)

IF Mode B: □50X75 Steel Tube
uses A7 Bolt for G10B--(2PCS each)

Mode B:50X75 Steel Tube



Please adjust the length between A1 to N
approximately to 1112mm
Suitable TO model:G6B,G5S,G10B



Please adjust the length between A1 to N
approximately to 862mm
Suitable TO model:G2B,G3S,G4I

