






Архангельск (8182)63-90-72	Ижевск (3412)26-03-58	Магнитогорск (3519)55-03-13	Пермь (342)205-81-47	Сургут (3462)77-98-35
Астана (7172)727-132	Иркутск (395)279-98-46	Москва (495)268-04-70	Ростов-на-Дону (863)308-18-15	Тверь (4822)63-31-35
Астрахань (8512)99-46-04	Казань (843)206-01-48	Мурманск (8152)59-64-93	Рязань (4912)46-61-64	Томск (3822)98-41-53
Барнаул (3852)73-04-60	Калининград (4012)72-03-81	Набережные Челны (8552)20-53-41	Самара (846)206-03-16	Тула (4872)74-02-29
Белгород (4722)40-23-64	Калуга (4842)92-23-67	Нижний Новгород (831)429-08-12	Санкт-Петербург (812)309-46-40	Тюмень (3452)66-21-18
Брянск (4832)59-03-52	Кемерово (3842)65-04-62	Новокузнецк (3843)20-46-81	Саратов (845)249-38-78	Ульяновск (8422)24-23-59
Владивосток (423)249-28-31	Киров (8332)68-02-04	Новосибирск (383)227-86-73	Севастополь (8692)22-31-93	Уфа (347)229-48-12
Волгоград (844)278-03-48	Краснодар (861)203-40-90	Омск (3812)21-46-40	Симферополь (3652)67-13-56	Хабаровск (4212)92-98-04
Вологда (8172)26-41-59	Красноярск (391)204-63-61	Орел (4862)44-53-42	Смоленск (4812)29-41-54	Челябинск (351)202-03-61
Воронеж (473)204-51-73	Курск (4712)77-13-04	Оренбург (3532)37-68-04	Сочи (862)225-72-31	Череповец (8202)49-02-64
Екатеринбург (343)384-55-89	Липецк (4742)52-20-81	Пенза (8412)22-31-16	Ставрополь (8652)20-65-13	Ярославль (4852)69-52-93
Иваново (4932)77-34-06	Киргизия (996)312-96-26-47	Казахстан (772)734-952-31	Таджикистан (992)427-82-92-69	

Единый адрес для всех регионов: bda@nt-rt.ru || www.bodysolid.nt-rt.ru

LPH-1100.1 OWNER'S MANUAL


HARDWARE ILLUSTRATION

A1. 1/2"X3"L Hex Head Bolt-----	[4PCS]
A2. 1/2"X3 1/4"L Hex Head Bolt-----	[6PCS]
A3. 1/2"X3 1/2"L Hex Head Bolt-----	[4PCS]
A4. 1/2"X5"L Hex Head Bolt-----	[3PCS]
A5. 1/2"X5 1/4"L Hex Head Bolt-----	[2PCS]
A6. 3/8X3/4"L Hex Head Bolt -----	[2PCS]
A7. 3/8"X3"L Hex Head Bolt-----	[4PCS]
A8. 5/16"X3/4" Hex Head Bolt-----	[4PCS]
A9. 5/16"X1" Co.Noid Head Bolt-----	[4PCS]
A10. 5/16"X1" Round Bolt-----	[13PCS]
A11. 5/16"X1 1/4" Hex Head Bolt-----	[2PCS]
A12. 5/16"X2 1/4" Hex Head Bolt-----	[2PCS]
B1. 1/2" Nylon Lock Nut-----	[19PCS]
B2. 3/8" Nylon Lock Nut-----	[4PCS]
B3. 5/16" Nylon Lock Nut-----	[4PCS]
C1. 1/2"(I.D.) Washer(Ø25)-----	[8PCS]
C2. 1/2"(I.D.) Washer(Ø34)-----	[30PCS]
C3. 3/8"(I.D.) Washer(Ø27)-----	[8PCS]
C4. 3/8"(I.D.) Washer(Ø30)-----	[2PCS]
C5. 5/16"(I.D.) Washer(Ø24)-----	[17PCS]
C6. 5/16" Spring Washer-----	[17PCS]
C7. 5/16" (I.D.)Washer(Ø18)-----	[8PCS]




HARDWARE ILLUSTRATION

D1. 1 3/4"X1 3/4" End Cap(9211-004)	[2PCS]
D2. 2"X2" End Cap(9211-006)	[7PCS]
D3. Ø50 Round End Cap(9211-020)	[2PCS]
D4. 2"X2"L Foot Cap(9211-024)	[7PCS]
D5. Ø20 Round End Cap(9211-036)	[4PCS]
D6. 2"x2" Rubber Dount (9212-010)	[2PCS]
D7. 38X75L Rubber Pad(9310-002)	[2PCS]
D8. 38X325L Rubber Pad(9310-042)	[1PCS]
D9. Ø1"x2.5t Round End Cap(9260-021)	[4PCS]
D10. 38X38 End Cap(9211-003)	[4PCS]
D11. 25X50 End Cap (9211-009)	[2PCS]



PARTS ILLUSTRATION SHEET


C[1PCS]




D[1PCS]




A[1PCS]




B[1PCS]




E[1PCS]



F[1PCS]




G[1PCS]



K[1PCS]




H[1PCS]



J[1PCS]




N[1PCS]




O[1PCS]



L[1PCS]



M[1PCS]



P[2PCS]



T[1PCS]




Q[1PCS]



R[1PCS]



S[1PCS]



U[1PCS]



V[1PCS]
8312-013



W[2PCS]
8343-023




X[1PCS]
8333-045




PARTS ILLUSTRATION SHEET


Y[1PCS]




Z[1PCS]




AA[1PCS]




AB[2PCS]




AC[1PCS]




AD[1PCS]




ASSEMBLY STEP 1




ASSEMBLY STEP 2




ASSEMBLY STEP 3




ASSEMBLY STEP 4




ASSEMBLY STEP 5




ASSEMBLY STEP 6



ASSEMBLY STEP 7Section View

ASSEMBLY STEP 8



Section View

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Казахстан (772)734-952-31

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Таджикистан (992)427-82-92-69

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: bda@nt-rt.ru || www.bodysolid.nt-rt.ru