


SRM-1700G SEATED ROW



Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06








Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Киргизия (996)312-96-26-47


Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Казахстан (772)734-952-31

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Таджикистан (992)427-82-92-69


Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

SRM-1700G HARDWARE ILLUSTRATION SHEET


	Qty.		Qty.
 A1. 1/2"X5 1/2" HEX HEAD BOLT -----	[2PCS]	 D1. 1/2" BOLT CAP -----	[44PCS]
 A2. 1/2"X5 1/4" HEX HEAD BOLT -----	[8PCS]	 D2. 2"X4" END CAP (9211-014)-----	[3PCS]
 A3. 1/2"X5" HEX HEAD BOLT -----	[2PCS]	D3. 50X50X1.8t END CAP (9211-087)----	[5PCS]
 A4. 1/2"X3 1/2" HEX HEAD BOLT -----	[2PCS]	D5. ø3/4" SHAFT COLLAR (9211-046)---	[2PCS]
 A5. 1/2"X2 1/4" HEX HEAD BOLT -----	[5PCS]	D6. 2"X4" FOOT CAP (9211-028)-----	[4PCS]
 A6. 1/2"X1 3/4" HEX HEAD BOLT -----	[4PCS]	D7. ø6" PULLEY (9213-009)-----	[1PCS]
 A7. 1/2"X1" HEX HEAD BOLT -----	[2PCS]	D8. ø4 1/2" PULLEY (9213-010)-----	[4PCS]
 A8. 3/8"X1 3/4" HEX HEAD BOLT -----	[1PCS]	D9. ø1"X135 RUBBER GRIP (9212-016)--	[2PCS]
 A9. 5/16"X1" HEX HEAD BOLT -----	[8PCS]	D10. ø4" RUBBER DONUT (9310-017)----	[2PCS]
 A10. 7/16"X1 1/2" ROUND BOLT -----	[1PCS]	D11. ø1"X2" RUBBER GRIP (9212-004)---	[2PCS]
 A11. 5/16"X5/16" SET SCREW -----	[3PCS]	D12. 38X75 RUBBER BAR CATCH (9310-002)---	[2PCS]
 A12. 5/8"X1 3/4" ROUND BOLT -----	[1PCS]	D13. 60X50 NYLON BUSHING (9211-033)-	[2PCS]
 A13. 10LB BALL PIN -----	[1PCS]	D14. CHROME TOP PLATE (8400-002)---	[1PCS]
 B1. 1/2" NYLON LOCK NUT -----	[23PCS]	D15. WEIGHT SELECTOR BAR (8220-060)-	[1PCS]
 B2. 3/8" NYLON LOCK NUT -----	[1PCS]	D16. 4340mm STEEL CABLE -----	[1PCS]
 B3. 5/8" LOCK NUT -----	[1PCS]	D17. 2"X4" RUBBER DOUNT (9212-009)--	[3PCS]
 C1. 1/2" (I.D)WASHER -----	[2PCS]	D18. ø1"X10" RUBBER GRIP (9310-029)--	[2PCS]
 C2. 3/8" (I.D)WASHER -----	[2PCS]	D19. ø5/8" ROUND END CAP (9211-015)-	[4PCS]
 C3. 5/16" (I.D)WASHER -----	[8PCS]		
 C4. 5/16" SPRING WASHER -----	[8PCS]		
 C5. 1/2" ROUND END CAP WASHER ----	[44PCS]		
 C6. 5/8" SPRING WASHER -----	[1PCS]		
 C7. 1/2"Xø25 (I.D)WASHER -----	[4PCS]		




A [1PCS]




B [1PCS]




C [1PCS]




D [1PCS]




E [1PCS]




F [1PCS]




G [1PCS]




H [1PCS]




I [2PCS]






J [1PCS]

M [2PCS]
8280-001


K [1PCS]



L [1PCS]

N [3PCS]
8312-077P [1PCS]
9121-012Q [1PCS]
9131-007R [2PCS]
8510-005

SRM-1700G




SRM-1700G

THERE IS A RISK ASSUMED BY INDIVIDUALS WHO USE THIS TYPE OF EQUIPMENT. TO MINIMIZE RISK, YOU MUST FOLLOW THESE RULES:

1. Inspect equipment before each workout. Check that all nuts, bolts, screws and pop pins are in place and fully tightened. Also, before use, check cables for signs of wear. Replace all worn parts immediately. Never use machine if any parts are damaged or missing. Failure to follow these rules may result in serious injury.
2. Keep clear of the cables and all moving parts when the machine is in use.
3. Always make sure all Snap Links are closed when doing any cable/pulley exercises.
4. Exercise with care. Perform your exercises at a smooth moderate pace; never perform jerky or uncoordinated movements that may cause injury.
5. It is recommended that you should workout with a training partner.
6. Do not allow children or minors to play on or around this equipment.
7. If unsure of proper use of equipment, call your local Body-Solid distributor or the Body-Solid customer service department at 1-800-556-3113.
8. **WARNING:** Consult your physician before starting your exercise program. For your own safety, do not begin any exercise program without proper instruction.

RAL2-11-98



SRM-1700G

SEATED ROW

